

SANITEASY - MODEL T. - DEVICE MANUAL

For safe and correct set-up and subsequent use of the device, please read the full online manual of the device.

Full manual available here: www.saniteasy.co/instructions



Scan to access
full device manual

Easy set up in **four** steps.

01



1. Place the device in the destination of use.
2. Make sure it is stable and adjust the position if necessary

02



1. Open the service panel in the back of the device.
2. Exchange the tank. Remember to carefully screw the cap with the bayonet with the tank.
3. Place the tank on the shelf.
4. Lock the service panel.

03



1. Place the cable in the socket on the back of the device
2. Plug the cable into the electricity.
3. Switch on the device.

04



1. By placing your hand below the sensor several times fill the system with the liquid.
2. The device is now ready to use.

ATTENTION:

This device is designed for indoor use only.

The operating liquid for this device has to be an H2O liquid (100% water-based).

Using a disinfectant in any other form such as gel or foam is not allowed and will destroy the device.

The manufacturer is not liable for any damages or any loss caused by the use of the device not in accordance with the provided user manual.

SAFETY PRECAUTIONS

CAUTION: NEVER TIP THIS DEVICE WHEN FLUID IS FILLED.

To minimize the risk of fire, electric shock, and injury, make sure you read the following precautions carefully when installing and using and act accordingly.

Failure to follow safety precautions in this manual could result in serious injury or death.

Do not perform the installation of the device without first reading this manual.

Use only original accessories provided by the manufacturer, authorized distributor, or reseller.

It is not allowed to interfere in any way with any electrical part of the device or to redesign it.

For smooth operation, it is advised to check regularly if the device is working properly, and in case of any doubt contact your distributor or service provider.

If you wish to use an extension cord, make sure it is a certified one and installed away from any sharp edges, heat sources, and flammable materials.

When pulling the cord out of the socket, hold the socket with one hand instead of pulling the cable by force.

This electrical device is not intended for use by unsupervised children, by persons with limited physical, sensual, or mental abilities, or persons without appropriate knowledge and/or experience, unless they work under the supervision of a person responsible for their safety or receive proper instructions from him or her on how the device should be used in a way that warrants safety.

It is not allowed to operate a device that has been damaged, is incomplete, or rebuilt without the manufacturer's consent.

Do not smoke near the device!

Don't use open fire near the device.

Make sure that the device is installed on a solid ground where it will not fall over or crash, also make sure it is placed in a place where there is no increased humidity and there is a safe distance from any place where the electrical part of the device could come in direct contact with water.



SANITEASY

safety is freedom



SANITEASY - MODEL T. DEVICE MANUAL

